

- Ventilator
- 2 Air flow: Air flows through the wire mesh into the drying box containing loose hav.
- 3 Gable roof overhang: Air travels through the steel roof, where the sun heats the air, warming it up as it travels through a duct to the dehumidifier.
- Airflow door: Acts as a switch from outside fresh air to circulating air already inside the building.

- 53 Dehumidifier entry: Air flows into dehumidifier where air cools and condensates.
- Dehumidifier exit: The heat that comes into the dehumidifier is put back into the air upon exit, creating dry, warm air.
- 6 Control box: Every part of the system is controlled here.